

**CR5000**  
QUICK START GUIDE



[www.codecorp.com](http://www.codecorp.com)



User Manual  
Manuel d'Utilisateur  
Manual de Usuario  
Manual do Usuário  
Benutzerhandbuch  
ユーザーマニュアル  
사용자 매뉴얼




Configuration Guide  
Guide de Configuration  
Guía de Configuración  
Guia de Configuração  
Programmierhandbuch  
設定コード表  
配置指南  
설정 가이드




[YouTube.com/codecorporation](https://www.youtube.com/codecorporation)

**Included if Ordered**


Inclus si commendé    Incluido si así lo ordena    Incluídos se ordenou  
Inbegriffen, wenn bestellt    注文時に追加    包括若订购    주문시 포함



Power Supply  
Alimentation électrique  
Fuente de alimentación  
Fonte de alimentação  
Netzteil  
ACアダプタ  
充电电源  
Power Supply




USB Cable  
Câble d'USB  
Cable USB  
Cabo USB  
USB-Kabel  
USB ケーブル  
USB 线缆  
USB 케이블



Power Adapter  
Daptateur d'alimentation  
Adaptador de poder  
Adaptador energia  
Netzteil  
電源アダプタ  
电源适配器  
전원 어댑터




T500 BT Cable  
Câble de T500 BT  
Cable t500 bt  
Cabo T500 BT  
T500 BT-Kabel  
T500 BT 케이블  
T500 BT 线缆  
T500 BT 케이블




RS232 Cable  
Câble de RS232  
Cable rs232  
Cabo RS232  
RS232-Kabel  
RS232 케이블  
RS232 线缆  
RS232 케이블

**Scanning**

Lecture    Escaneo    Leitura    Scannen  
스캐닝    扫描中    스캐닝




-15° to 45°




# Set Up

Installation   Instalación   Instalação  
Einrichten   設定   設置   셋업



# Power On

Allumer   Encender   Ligar   Einschalten  
電源オン   电源开启   Power on



# Bluetooth® Connection via T500 BT Cable

Connexion Bluetooth   Conexión bluetooth   Conexão Bluetooth  
Bluetooth-Verbindung   Bluetooth 接続   蓝牙连接   블루투스 연결

